

<b>Subject:</b> <b>KEYLESS ENTRY REMOTE TRANSMITTER ( KEY FOB ) BATTERY REPLACEMENT CAUTION</b>	<b>Bulletin No:</b> 09-041/10
	<b>Last Issued:</b> 08/30/2010

## APPLICABLE MODEL(S)/VINS

2011 Mazda2  
2004-2011 Mazda3  
2006-2010 Mazda5  
2003-2011 Mazda6  
2007-2011 CX-7  
2007-2011 CX-9  
2003-2011 MX-5  
2004-2011 RX-8

## DESCRIPTION

When replacing a keyless entry remote transmitter battery, take caution or transmitter damage may occur.

To avoid damaging the keyless transmitter during battery replacement, make sure to follow the service points shown below.

## BATTERY REPLACEMENT SERVICE POINTS

1. Before opening the transmitter for battery replacement, touch a metal object to ground static electricity from your body.
2. Replace the battery with clean and dry hands.
3. Do NOT touch any of the circuitry on the transmitter.
4. Replace with designated battery.
5. Do NOT install the new battery with its polarity reversed.
6. Verify proper operation of the keyless entry remote system.  
If keyless entry remote transmitter doesn't work, check battery:
  - Polarity
  - Part number
  - Terminal tension